


KA 254b Smart Classroom Instructions

If you are having difficulties using equipment in this room, call extension **3166**



Powering System Up

- 1) Obtain **Epson Remote**.
- 2) Point remote at front of projector.
Press power button one time.
Remember: Projector will take 30 seconds to come on.






Using Console Computer

- 1) Verify that the **Video Switch Box** is set to "PC."
- 2) Power up computer.
- 3) Log on to computer.
Your User Name is the first part of your HSU email address.
Password is your HSU email password.
- 4) Amplifier is in standby mode, with a red indicator light. **Press the red light.** It will blink and in 3 to 5 seconds will change to **blue**, indicating it's powered up and ready for use. Turn **amplifier selector knob** to **PC**.
- 5) **If there is no image being projected:**
Obtain **Epson remote**.
Press the **Source Search** button. Follow on-screen options.



Using a Laptop

- 1) Shut down your laptop.
- 2) Verify that the **Video Switch Box** is set to "Laptop"
- 3) Connect the **Laptop Video cable** to the video output port on your laptop.
Please note: the Laptop Video cable is VGA-compatible only. Certain laptop models will require a DVI-to-VGA adaptor or a Mini-VGA adaptor. Consult your owner's manual for further information.
- 4) For Internet connectivity, connect to the current HSU wireless network option that is available.
Please note: you will need to "register" your laptop before connecting to the campus network. Contact your college ITC or the Help Desk for further information.
- 5) For laptop audio output, connect the **laptop audio cable** to your headphone jack. The amplifier is in standby mode, with a red indicator light. **Press the red light.** It will blink and in 3 to 5 seconds will change to **blue**, indicating it's powered up and ready for use. Turn **amplifier selector knob** to **PC**, and move selector knob to **Laptop**. Make sure your laptop's audio is not muted and that the speakers are powered on.
- 6) Connect your laptop's AC adaptor to a power outlet and start up your laptop.
- 7) **If there is no image being projected:** Obtain **Epson remote**. Press the **Source Search** button. Follow on-screen options.
- 8) If you still do not see an image, refer to **laptop troubleshooting guide** on page 4.
- 9) When finished, shut down your laptop and disconnect all cables. Please turn the switch back to "PC."
- 10) Proceed to shutting down the rest of the equipment. Follow the instructions on page four of this guide, **Powering Down the System**



Playing a DVD/VHS Tape

- 1) Power on **amplifier**.
Turn **selector knob** to **DVD/VCR**.
- 2) Power on **DVD/VHS Player** and load media.
- 3) If there is no image being projected, obtain **Epson remote**. Press the **Source Search** button. Follow on-screen options.
- 4) Adjust volume as necessary.
- 5) For advanced DVD features, such as subtitles, use the **DVD/VHS remote control**



1



2



3

Using Closed Captioning

- 1) For **DVDs**, use the DVD remote and the DVD menu to set closed captioning or subtitle options.
- 2) For **VHS videocassettes**, set the closed caption device switch to the CC1 position.


When finished with video, please set the switch to the Off position.



2


Powering down the system

- 1) Shut down any computers running.
- 2) Obtain the **Epson remote**, and point it at the projector on the ceiling. Press the “power” button twice until the screen goes back.
- 3) Eject media and turn off the **DVD/VHS Player**.
- 4) Power off the **amplifier**.
- 5) Set the **closed captioning device** to the Off position.



Laptop Troubleshooting


For PC Laptops: Depending on your model of laptop, you may need to toggle the display mode. For example, on many laptops, you must hold down the **function key (FN)** located in the lower left-hand corner of the keyboard, and at the same time, press the **video toggle key**, which is located along the top of the keyboard. Look for the text **CRT/LCD** or an icon of a **display and a laptop**.



Examples of video toggle keys

For Mac Laptops:

- 1) Go to **System Preferences/Display**.
- 2) Select the **Arrangement** tab and check the **Mirror Displays** box.



Who to Call For Assistance

If you are having any difficulties using equipment in this room, call extension **3166**

This set of instructions are applicable to the following smart classrooms:

Kinesiology and Athletics 254B

Fall 2019